

# *NET9000 Fieldbus Connections*

## *911x-NI FNICO power supplies*



**Instruction Manual**





# CONTENTS

<b>1</b>	<b>ABOUT THIS MANUAL</b> .....	<b>1</b>
1.1	Product description .....	1
<b>2</b>	<b>INSTALLATION</b> .....	<b>1</b>
2.1	Mounting & enclosure requirements .....	1
2.3	Signal and power connections .....	3
2.5	Making connections .....	3
2.6	Finishing .....	3
<b>3</b>	<b>SETUP AND TESTING</b> .....	<b>4</b>
3.1	Switches .....	4
3.2	Testing .....	4
3.3	Tag labelling .....	4
<b>4</b>	<b>MAINTENANCE</b> .....	<b>4</b>
4.1	Routine maintenance .....	4
4.2	Enclosures .....	4
<b>5</b>	<b>FBT1-IS FIELDBUS TERMINATOR</b> .....	<b>5</b>
5.1	Wiring connections .....	5
<b>6</b>	<b>APPENDIX A - ATEX information</b> .....	<b>6</b>

## IMPORTANT NOTICE

The user's attention is drawn to the important safety information provided in Appendix A.





## 1 ABOUT THIS MANUAL

The purpose of this manual is to provide the user with information on the installation, connection, test and maintenance of the MTL911X-NI Series Fieldbus Non-Incendive COnccept (FNICO) power supplies.

**"Cautionary Note:** In common with all other electrical apparatus installed in hazardous areas, this apparatus must only be installed, operated and maintained by competent personnel. Such personnel shall have undergone training, which included instruction on the various types of protection and installation practices, the relevant rules and regulations, and on the general principles of area classification. Appropriate refresher training shall be given on a regular basis. [See clause 4.2 of EN 60079-17].

This instruction manual supplements the requirements of nationally accepted codes of practice, for example, IEC/EN 60079-14 in Europe and the National Electrical Code, combined with ANSI/ISA-RP 12.12 in the USA. All installations should comply with the relevant sections of these codes.

In addition, particular industries or end users may have specific requirements relating to the safety of their installations, and these requirements should also be met".

### 1.1 Product description

The 9111-NI and 9112-NI are fieldbus repeater isolators that can relay fieldbus signals between a host in a safe, or Zone 2 / Division 2 hazardous area and non-incendive devices in a Zone 2/ hazardous area. They provide DC power and an impedance terminator to the non-incendive NI fieldbus and also, if required, to the host fieldbus.

#### 1.1.1 Model 9111-NI

This can provide 180mA current, which typically would power at least nine field devices in IEC Gas Group IIC\* environments, where a typical device is considered to have a current consumption of 20mA.

\* Equivalent to Class I, Gas Groups A and B in N. America

† Equivalent to Class I, Gas Group C in N. America

#### 1.1.2 Model 9112-NI

For Gas Group IIB† environments the 9112-NI can provide a higher output current of 320mA, which will power up to sixteen field devices rated at 20mA.

## 2 INSTALLATION

### 2.1 Mounting & enclosure requirements

#### 2.1.1 General

These power supplies may be mounted in safe areas, Zone 2 or Division 2 hazardous areas but, wherever they are located, the mounting conditions must:


- prevent any form of pollution that could compromise the operation, or safety of the unit. For example, an unpolluted location or a suitable enclosure could be chosen.
- provide an adequate level of mechanical protection. This can be achieved by selecting a protected location, a suitable enclosure, or a combination of both.
- ensure that all cable entries and connections are secure.
- ensure that the trunk cable complies with local and national codes of practice for the segregation of nonincendive/energy-limited wiring from other forms of wiring.
- provide adequate security against unauthorised interference.
- ensure that the permitted ambient temperature range of the units
 

9111-NI	-40°C to +70°C
9112-NI	-40°C to +60°C

is not exceeded. Power dissipation within the enclosure and the use of shading against direct sunlight should be considered.

#### 2.1.2 Outdoor mounting

Where power supplies are mounted in outdoor locations then the use of a suitably approved enclosure is recommended. For Zone 2 locations, Ex e or Ex n enclosures are an economic solution that satisfy the minimum acceptable criteria of a 7Nm impact test and IP54 ingress protection. However, in some locations a higher degree of ingress protection or corrosion resistance may be necessary or desirable. The emphasis should be placed on the suitability for the application rather than the extent of certification.



**Figure 1 Dimensions of 9111x-NI**

## 2.2 Mounting

### 2.2.1 Orientation

The 9111x-NI Series power supplies can be mounted on type T35 (top hat) DIN-rail, or surface mounted. In either case, the orientation must allow air to be naturally convected through the unit to achieve the maximum cooling effect. To make use of the full temperature range specified for a unit it must be mounted on a vertical surface with the switches at the top - as shown in the right-hand part of Figure 1.


### 2.2.2 Mounting FNICO power supplies on DIN rail

Press the unit onto the DIN rail (type T35) as shown in figure 2, with the non-incendive (NI) terminals (marked with grey labels) facing the field wiring connections.



**Figure 2 - Mounting on DIN rail**


To remove a unit from the rail, insert a screwdriver blade into the clip as shown in figure 3 and lever the clip gently outwards; pivot the isolator off the rail.



**Figure 3 - Removing from DIN rail**

### 2.2.3 Surface mounting FNICO power supplies

To surface mount a 9111X - NI power supply, ease out the DIN rail clips at each end (in the manner shown in Figure 3) to reveal mounting brackets, which contain clearance holes for M4 screws or bolts.




**Figure 4 - Surface mounting brackets**

## 2.3 Signal and power connections

### 2.4.1 General

All units have removable signal and power plugs. The plugs can be supplied with either screw-clamp (911X-NI-PS) or sprung cage-clamp (911X-NI-PC) terminals as shown in figure 5.




**Figure 5 - Spring clamp and screw clamp connectors.**

The user can decide whether it will be easier to wire the power supply with the connector plugs in-situ, or to remove them. If the connectors are removed for wiring, ensure that the correct one is being wired; the plugs use a mechanical key system to prevent accidental cross connection - they are NOT interchangeable.

Ensure that enough cable is provided to permit future removal of the plugs for maintenance or replacement.

To remove a connector plug insert a screwdriver blade behind it as shown in figure 6 and lever the connector gently outwards.




**Figure 6 - Removing power and signal connectors**

The conductors or ferrules used with these connectors should be between 14 and 24 AWG (1.6 and 0.5mm dia) in size. If two large conductors need to be accommodated, e.g. two -ve connections on the Power connector, then a twin ferrule should be used.

### 2.4.2 Host and NI fieldbus connections

The block diagram (Figure 7) shows terminals 5 and 8 marked with an 'S'. This indicates a termination point for the fieldbus cable screen. These are termination points only, with no internal connection.



**Figure 7 - Power supply block diagram**

### 2.4.3 Power connection

The 911X-NI units can accommodate two power inputs for applications that require redundancy. Internal steering diodes ensure correct power sharing.

Connect supplies as indicated below.

		+ ve to terminal	-ve to terminal
<b>Single power input</b>	Power 1	1 or 3	2
<b>Redundant power</b>	Power 1	1	2
	Power 2	3	2

## 2.5 Making connections

### 2.5.1 Screw clamp connector

- Strip back the insulation of conductors (7mm - recommended strip length - See note).
- Check the terminal assignments, as indicated on the side label of the unit.
- Insert conductor into connector and tighten screws.

### 2.5.2 Spring (cage) clamp connector

- Strip back the insulation of conductors (10 mm - recommended strip length - See note).
- Check the terminal assignments, as indicated on the side label of the unit.
- Press screwdriver blade into groove on spring clamp; fully insert conductor; remove screwdriver.

Note If the wires are to be fitted with crimp ferrules consult ferrule manufacturer's recommendation.

## 2.6 Finishing


Wire up individual FNICO power supplies in accordance with wiring schedules. Power supply connections can be onward linked from one power plug to the next (i.e. 'daisy-chained').

## 3 SETUP AND TESTING

### 3.1 Switches

Two switches are provided on the front face of the power supply, located in the top right-hand corner. Operation of these switches requires the use of a small screwdriver, or similar.

**Figure 8 - Host power supply and host trunk terminator switches**



#### 3.1.1 "Host Pwr" switch

Some host fieldbus I/O cards need to draw 10–20mA of current from the fieldbus in order to operate. If this is required, the "Host Pwr" switch on the 911X–NI unit should be set to the ON position. The voltage provided on the fieldbus is in the range 14–32 V dc, at a maximum current of 30 mA.

**IMPORTANT** - If more than one 911X–NI power supply is connected to the same host segment, **only one** of them should have its "Host Pwr" switched to the ON position. All the others on this same host segment must have their "Host Pwr" switch set to OFF.

#### 3.1.2 Terminator switch

**A terminator is required at each end of a fieldbus segment.** If a single 911X–NI power supply is connected to the remote end of a host segment, a terminating impedance must be applied by setting its "T (Host)" switch to ON. A fieldbus terminator must also be applied, or connected, at the host end of the segment.

**IMPORTANT** - If more than one 911X–NI power supply is connected to the same host segment, **only one** of them should have its "T (Host)" terminator switch set to ON. All the others on this same host segment must have their "T (Host)" switch set to OFF.

### 3.2 Testing

The following checks refer to the LED indicators (see Figure 9)

#### Power LED (green)

This should normally be ON. If not, check the power connections.

#### Fault LED (red)


This should normally be OFF. If it is ON, it indicates:

- (a) a short circuit on the NI fieldbus or,
- (b) excessive transmitter load, i.e. too many field devices.

#### Host or NI LED (yellow)

Both of these should normally be ON.

OFF indicates a permanent comms error and flashing indicates an occasional communications error.



**Figure 9 - FNICO power supply tag area and LED's**

### 3.3 Tag labelling

Space has been provided on the front label to apply a self-adhesive tag label. The space for a tag label is located above the LED indicators and measures 30mm wide by 9mm high. See Figure 9.

## 4 MAINTENANCE

### IMPORTANT NOTE

If any power supply is suspected of being faulty, return it to the MTL Group Company, or the representative from whom it was purchased, for repair or replacement. **DO NOT make repairs or modifications.** *The safe operation of the unit, and hence the safety of the site, can be affected by unauthorised changes.*

Tests and maintenance checks should be limited to those described in this and the Testing section.

### 4.1 Routine maintenance

Check the general condition of the installation occasionally to make sure that no deterioration has occurred. At least once every two years (and more frequently for particularly harsh environments), check that:

- a) power supplies are of the types specified in the relevant documentation;
- b) power supplies and connectors are correctly and legibly tagged, connectors are plugged into the corresponding power supplies and tag details comply with the relevant documentation;
- c) power supplies are securely clipped to the DIN rail;
- d) all cable connections are properly made to the plugs;
- e) all plugs are fully inserted;
- f) all connecting cables are of the specified type and rating; are correctly routed and segregated (particularly when fitted in enclosures) and are not frayed or otherwise damaged;
- g) all cable screens are properly earthed;
- h) there is no sign of damage or corrosion.

If the outer case of a FNICO unit requires cleaning, use a cloth dampened with a dilute mixture of detergent and water. Special care should be taken to ensure that no liquid or debris enters the unit via the ventilation slots.

### 4.2 Enclosures

The only maintenance needed for enclosures is cleaning and periodic visual inspections. Clean external surfaces only, using soap and water; do not use chemical solvents or proprietary cleaning fluids.


Every year, or more frequently in harsh environments, inspect enclosures and check that they are mounted securely and show no signs of damage that would impair their performance.

Remove any accumulation of water inside (using the drain plug, if fitted). Check cable gland nuts are still tight and that all connections are properly made.




## 5 FBT1-IS FIELDBUS TERMINATOR

The FBT1-IS is a DIN rail mounting unit that provides the correct termination for fieldbus circuits in either safe or hazardous areas. The unit is certified intrinsically safe and may be used in non-incendive fieldbus circuits in Zone 2, IIC, T4 locations. It fully complies with the electrical characteristics requirements of section 22.7.5 of appropriate fieldbus standards. Applicable fieldbus standards and specifications are IEC61158-2, ISA-S50.02 for 31.25kbit/s fieldbus systems and FOUNDATION™ Fieldbus 31.25kbit/s Physical Layer Profile Specification FF816.




**Figure 10 - FBT1-IS fieldbus terminator**

Further information on fieldbus termination can be found in MTL's AB001 and AB002 application briefs.



**Figure 11 - Dimensions of the FBT1-IS**

### 5.1 WIRING CONNECTIONS



**Figure 12 - Schematic diagram of the FBT1-IS**

In addition to the connections for the fieldbus signal wiring (C,D,E & F), the FBT1-IS also provides screw terminals (A & H) for terminating the fieldbus screen.

## 6 APPENDIX A - ATEX INFORMATION

The Essential Health and Safety Requirements (Annex II) of the EU Directive 94/9/EC [the ATEX Directive - safety of apparatus] requires that the installation manual of all equipment used in hazardous areas shall contain certain information. This annex is included to ensure that this requirement is met. It compliments the information presented in this document and does not conflict with that information. It is only relevant to those locations where the ATEX directives are applicable.

### 6.1 General

- In common with all other electrical apparatus installed in hazardous areas, this apparatus must only be installed, operated and maintained by competent personnel. Such personnel shall have undergone training, which included instruction on the various types of protection and installation practices, the relevant rules and regulations, and on the general principles of area classification. Appropriate refresher training shall be given on a regular basis. [See clause 4.2 of EN 60079-17].
- This apparatus has been designed to meet the requirements of associated electrical apparatus in accordance with EN 50021 and EN50014.
- This apparatus has been designed and manufactured so as to provide protection against all the relevant additional hazards referred to in Annex II of the directive, such as those in clause 1.2.7.

### 6.2 Installation

- The installation should comply with the appropriate European, national and local regulations, which may include reference to the IEC code of practice IEC 60079-14. In addition particular industries or end users may have specific requirements relating to the safety of their installations and these requirements should also be met. For the majority of installations the Directive 1999/92/EC (the ATEX Directive - safety of installations) is also applicable.
- This apparatus is an associated electrical apparatus and is normally mounted in a non-hazardous area [safe] area. It also meets the requirements of Category 3 apparatus and may be installed in a Zone 2 location providing that the relevant installation conditions are met. When mounted in a Zone 1 location the apparatus must be provided with an enclosure, which offers an additional degree of protection appropriate to the area classification.
- This apparatus must not be subjected to mechanical and thermal stresses in excess of those permitted in the certification documentation, this manual and the product specification. If necessary the product must be protected by an enclosure to prevent mechanical damage.
- The apparatus must not be installed in a position where it may be attacked by aggressive substances and must be protected from excessive dust, moisture and other containments by an enclosure.

### 6.3 Inspection and maintenance

- Inspection and maintenance should be carried out in accordance with European, national and local regulations which may refer to the IEC standard IEC 60079-17. In addition specific industries or end users may have specific requirements which should also be met.
- Access to the internal circuitry must not be made during operation.
- If the outer enclosure of the apparatus needs to be cleaned, this should be done with a cloth lightly moistened by a dilute mixture of detergent in water.


### 6.4 Repair


- The products cannot be repaired by the user and must be replaced with an equivalent certified product. Repairs should only be carried out by the manufacturer or his authorised agent.



## 6.5 Marking

- The products each have their own labels which are reproduced below. In addition the serial number and/or date of manufacture are marked on the individual apparatus. This manual applies to products manufactured and date marked during or after the year 2003 .

**9111-NI**      **FNICO Power Supply - IIC**  
 $-40^{\circ}\text{C} \leq \text{Ta} \leq +70^{\circ}\text{C}$

 Use in Cl. I, Div. 2, Groups A,B,C,D T4 and Cl. I, Zone 2, Group IIC T4  
 Approved Non-incendive Field Terminals for Cl. I, II, III, Div. 2, Groups A,B,C,D,E,F,G and Cl. I, Zone 2, Group IIC  
 Install per SCI-975

Doc. No. MTL03ATEX9111X  
 II 3 GD EEx nA [L] IIC T4

  
 Made in Luton, England  
 MEASUREMENT TECHNOLOGY LTD. 3113/1 


**9112-NI**      **FNICO Power Supply - IIB**  
 $-40^{\circ}\text{C} \leq \text{Ta} \leq +60^{\circ}\text{C}$

 Use in Cl. I, Div. 2, Groups C,D T4 and Cl. I, Zone 2, Group IIB T4  
 Approved Non-incendive Field Terminals for Cl. I, II, III, Div. 2, Groups C,D,E,F,G and Cl. I, Zone 2, Group IIB  
 Install per SCI-975


Doc. No. MTL03ATEX9112X  
 II 3 GD EEx nA [L] IIB T4



  
 Made in Luton, England  
 MEASUREMENT TECHNOLOGY LTD. 3072/1 

Fieldbus Terminator FBT1-IS



WARNING  
 ELECTROSTATIC HAZARD, CLEAN ONLY  
 WITH A MOIST CLOTH AND DETERGENT

 Baseefa02ATEX0042  
 II 1G EEx ia IIC T4  
 $-40^{\circ}\text{C} \leq \text{Ta} \leq +70^{\circ}\text{C}$

 1180  
 Made in Luton, Beds, England by  
 Measurement Technology Ltd



**MTL Instruments Pty Limited**

1/30 Canvale Road  
Canning Vale  
Perth, WA 6155  
Australia  
Tel: +61 (0)8 9455 2994 Fax: +61 (0)8 9455 2805  
E-mail: enquiries@mtlaus.com.au

**MTL Canada Safety Instrumentation**

#102, 4249 97 Street  
Edmonton, Alberta  
Canada T6E 5Y7  
Tel: +1 780 485 3132 Fax: +1 780 485 3122  
E-mail: cinfo@mtlnh.com

**MTL Instruments Pte**

Room 1002A, The Gateway  
No 10 Yabao Road, Chaoyang District  
Beijing 100020  
China  
Tel: +86 010 8562 5718/5720/5721 Fax: +86 010 8562 5725  
E-mail: bjsales@mtl-inst.cn

**MTL Instruments sarl**

Les Carrés du Parc  
10 rue des Rosiéristes  
69410 Champagne au Mont d'Or  
France  
Tel: +33 (0)4 78 64 98 32 Fax: +33 (0)4 78 35 79 41  
E-mail: info@mtl-inst.fr

**MTL Instruments GmbH**

An der Gumpgesbrücke 17  
D-41564 Kaarst  
Germany  
Tel: +49 (0)2131 718930 Fax: +49 (0)2131 7189333  
E-mail: info@mtl.de

**MTL India Pvt. Limited**

No. 36, Nehru Street  
Off Old Mahabalipuram Road  
Sholinganallur  
Chennai - 600 119  
India  
Tel: + 91 (0)44 24501660/24501857 Fax: + 91 (0)44 24501463  
E-mail: sales@mtlindia.com

**MTL Italia srl**

Via Cantù 11  
I - 20092 Cinisello Balsamo MI  
Italy  
Tel: +39 (0)2 61802011 Fax: +39 (0)2 61294560  
E-mail: info@mtl-inst.it

**MTL Instruments KK**

3rd Floor, Gotanda Masujima Building  
1-8-13 Higashi-Gotanda, Shinagawa-Ku  
Tokyo 141-0022  
Japan  
Tel: +81 (0)3 5420 1281 Fax: +81 (0)3 5420 2405  
E-mail: sales@mtlkk.co.jp

**MTL Instruments BV**

PO Box 55, 6680 AB Bommel  
de Houtakker 36, 6681 CW Bommel  
The Netherlands  
Tel: +31 (0)481 450250 Fax: +31 (0)481 450260  
E-mail: info@mtlbenelux.com

**MTL Instruments Pte Limited**

31 Ubi Road 1  
#04-01 Aztech Building  
Singapore 408694  
Tel: +65 6 487 7887 Fax: +65 6 487 7997  
E-mail: sales@mtlsing.com.sg

**MTL Instruments**

Villa No. 4, Sector 2-17,  
Street 6  
PO Box 53234,  
Abu Dhabi, UAE  
Tel: +971 2 446 6840 Fax: +971 2 446 6841  
E-mail: mtlgulf@mtl-inst.com

**Measurement Technology Limited**

Power Court, Luton, Bedfordshire  
England LU1 3JJ  
Tel: +44 (0)1582 723633 Fax: +44 (0)1582 422283  
E-mail: enquiry@mtl-inst.com

**MTL Incorporated**

4001 W. Sam Houston Parkway N. Suite 150, Houston TX 77043  
USA  
Tel: +1 281 571 8065 Fax: +1 281 571 8069  
E-mail: info@mtl-inst.com

